

CDJ-3000X

MULTI PLAYER
LECTEUR DE MULTI
TORE-PLAYER
LETTORE MULTIPLO
MULTI-SPELER
MULTI REPRODUTOR
MULTI LEITOR
МНОГООФУНКЦИОНАЛЬН
ПРОИГРЫВАТЕЛЬ
Wielofunkcyjny

Precautions for Use
Précautions à l'utilisation
Hinweise für den Gebrauch
Precauzioni
Voorzorgsmaatregelen
Precauciones al usar
Precauções
Правила предосторожности при эксплуатации
Środki ostrożności przy użytkowaniu

alphatheta.com/support/
alphatheta.com/support/France/
alphatheta.com/support/Germany/
alphatheta.com/support/Italy/
alphatheta.com/support/Netherlands/
alphatheta.com/support/Spain/
alphatheta.com/support/Portugal/
alphatheta.com/support/Russia/
alphatheta.com/support/Poland/
rekordbox.com

For FAQ and other support information for this product, visit the websites above.

Pour consulter la FAQ et d'autres informations d'assistance concernant ce produit, visitez les sites Web ci-dessus.

Häufig gestellte Fragen und andere Supportinformationen zu diesem Produkt finden Sie auf den oben genannten Websites.

Per la sezione FAQ e altre informazioni di supporto per questo prodotto, visitare i siti web indicati sopra.

Bezoek de bovengestelde websites voor vaak gestelde vragen en andere informatie over ondersteuning voor dit product.

Para consultar las preguntas más frecuentes y otras informaciones de asistencia para este producto, visite los sitios web indicados anteriormente.

Para ver as perguntas frequentes e obter outras informações de assistência relativa a este produto, consulte os sites indicados acima.

Часто задаваемые вопросы и другое информирование о поддержке данного изделия см. на перечисленных выше сайтах.

W celu zapoznania się z odpowiedziami na często zadawane pytania i innymi informacjami pomocniczymi dotyczącymi tego produktu należy przejść na powyższe strony internetowe.

IMPORTANT SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions by the manufacturer, or sold with the apparatus. When a card, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a card is used, use caution when moving the car/apparatus combination to avoid injury from tip-over.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, connections, receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a card is used, use caution when moving the car/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

FEDERAL COMMUNICATIONS COMMISSION DECLARATION OF CONFORMITY	
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.	
Product Name: MULTI PLAYER Model Number: CDJ-3000X Responsible Party Name: AlphaTheta Music Americas, Inc. OPERATIONS DIVISION Address: 2050 W. 190th Street, Suite 109, Torrance, CA 90504, U.S.A. Phone: 1-424-498-0480 URL: alphatheta.com	This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.
Product Name: MULTI PLAYER Model Number: CDJ-3000X Responsible Party Name: AlphaTheta Music Americas, Inc. OPERATIONS DIVISION Address: 2050 W. 190th Street, Suite 109, Torrance, CA 90504, U.S.A. Phone: 1-424-498-0480 URL: alphatheta.com	This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses, and can radiate radio frequency energy and it is intended that it be used in conjunction with the following precautions to minimize the radio frequency interference and to ensure maximum protection against such interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Specifications	
General Power requirements AC 110 V ~ 240 V, 50 Hz/60 Hz Power consumption 45 W Power consumption (off) 0.3 W Main unit weight 6.0 kg/13.2 lb Max. external dimensions (W × D × H) 344.6 × 490.4 × 130.1 mm/13.6" × 19.3" × 5.1" Tolerable operating humidity 5% ~ 85% (no condensation) Tolerable operating temperature +5 °C ~ +35 °C (+41 °F ~ +95 °F) Output terminals RCA terminal	
Analog audio output (AUDIO OUT L/R) Output terminals RCA terminal Output level 2.0 Vrms (1 kHz) Frequency response 20 Hz ~ 40 kHz S/N ratio 115 dB Total harmonic distortion 0.0018 %	
Digital audio output (DIGITAL OUT) Output type Coaxial digital (S/PDIF) Output level 0.5 Vp-p (75 Ω) Output format 96 kHz, 24 bit	
USB downstream section (USB) Port USB Type-A Power supply 5 V/1.5 A or less USB Type-C Power supply 5 V/1.5 A or less	
USB upstream section (USB) Port USB Type-C	

English	
CAUTION TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.	
WARNING The equipment is not waterproof. To prevent a fire or shock hazard, do not place any container filled with liquid near this equipment (such as a vase or flower pot) or expose it to dripping, splashing, rain or moisture.	
WARNING The product is equipped with a three-wire grounding (earthed) plug - a plug that has a third grounding prong. This plug only fits a grounding-type power outlet. If you are unable to insert the plug into an outlet, contact a licensed electrician to replace the outlet with a properly grounded one. Do not defeat the safety purpose of the grounding plug.	
WARNING To prevent a fire hazard, do not place any naked flame sources (such as a lighted candle) on the equipment.	
Operating Environment Operating environment temperature and humidity: +5 °C to +35 °C (+41 °F to +95 °F); less than 85 %RH (cooling vents not blocked) Do not install this unit in a poorly ventilated area, or in locations exposed to high humidity or direct sunlight (or strong artificial light).	
VENTILATION CAUTION When installing this unit, make sure to leave space around the unit for ventilation to improve heat radiation (at least 5 cm at rear, and 5 cm at each side).	
CAUTION The "O" switch on this unit will not completely shut off all power from the AC outlet. Since the power cord serves as the main disconnect device for the unit, you will need to unplug it from the AC outlet to shut down all power. Therefore, make sure the unit has been installed so that the power cord can be easily unplugged from the AC outlet in case of an accident. To avoid fire hazard, the power cord should also be unplugged from the AC outlet when left unattended for a long period of time (for example, when on vacation).	
When using this product, confirm the safety information shown on the bottom of the unit.	
The graphical symbol ~ placed on the product means alternating current. The graphical symbol ~ placed on the product means direct current. The graphical symbol ~ placed on the product means Class II equipment.	
CAUTION This product is evaluated in moderate and tropical climate condition.	
[for a service technician] CAUTION Since the fuse may be in the neutral of the mains supply, disconnect the mains to de-energize the phase conductors.	
WARNING Store small parts out of the reach of children and infants. If accidentally swallowed, contact a doctor immediately.	
WARNING Do not touch any part of the reach of children and infants. If accidentally swallowed, contact a doctor immediately.	
POWER-CORD CAUTION Handle the power cord as the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or on the cord. Never make a knot in the cord or tie it with other cords. The power cords should be routed such that they are not likely to be stepped on. A damaged power cord can cause a fire or give you an electrical shock. Check the power cord once in a while. When you find it damaged, ask your nearest service center or your dealer for a replacement.	
○ switch Turn this unit on and off.	
• This unit should not be used by persons who have heart pacemakers installed, since adverse effects could occur. • Do not use this unit in hospitals or clinics, or near medical equipment. • Do not use inside airplanes or in the vicinity of automatic doors to avoid danger of causing malfunctions.	

Private households in the member states of the EU, in Switzerland, Norway, Iceland, Liechtenstein and UK may return their used electronic products free of charge to designated collection facilities or to a retailer (if you purchase a similar new one).

For countries not mentioned above, please contact your local authorities for the correct method of disposal.

By doing so you will ensure that your disposed product undergoes the necessary treatment, recovery and recycling and thus prevent potential negative effects on the environment and human health.

For Finland customers: Appareet mit illoksidat stikkontakti
For Sweden customers: Apparatet ska anslutas till jordat uttag
For Denmark customers: Apparatet skloppe skal tilsluttes en stikkontakt med jord, som giver forbindelse til sløjfeprops jord.

For U.S.A., U.S. Territories, and Canada
The Safety of Your Ears is in Your Hands
Get the most out of your equipment by playing it at a safe level - a level that lets the sound come through clearly without annoying ringing or distortion and, most importantly, without affecting your sensitive hearing. Sound can be deceiving. Over time, your "hearing comfort" level adjusts to higher volumes of sound, so what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adjusts.

ESTABLISH A SAFE LEVEL:
• Set your volume control at a low setting.
• Slowly increase the sound level until you can hear it comfortably and clearly, without distortion.
• Once you have established a comfortable sound level, set the dial and leave it there.

BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:
• Do not turn the volume up so high that you can't hear what's around you.
• Use caution or temporarily discontinue use in potentially hazardous situations.
• Do not use headphones while operating a motorized vehicle, the use of head phones may create a traffic hazard and is illegal in many areas.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

English	
CAUTION TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.	
WARNING The equipment is not waterproof. To prevent a fire or shock hazard, do not place any container filled with liquid near this equipment (such as a vase or flower pot) or expose it to dripping, splashing, rain or moisture.	
WARNING The product is equipped with a three-wire grounding (earthed) plug - a plug that has a third grounding prong. This plug only fits a grounding-type power outlet. If you are unable to insert the plug into an outlet, contact a licensed electrician to replace the outlet with a properly grounded one. Do not defeat the safety purpose of the grounding plug.	
WARNING To prevent a fire hazard, do not place any naked flame sources (such as a lighted candle) on the equipment.	
Operating Environment Operating environment temperature and humidity: +5 °C to +35 °C (+41 °F to +95 °F); less than 85 %RH (cooling vents not blocked) Do not install this unit in a poorly ventilated area, or in locations exposed to high humidity or direct sunlight (or strong artificial light).	
VENTILATION CAUTION When installing this unit, make sure to leave space around the unit for ventilation to improve heat radiation (at least 5 cm at rear, and 5 cm at each side).	
CAUTION The "O" switch on this unit will not completely shut off all power from the AC outlet. Since the power cord serves as the main disconnect device for the unit, you will need to unplug it from the AC outlet to shut down all power. Therefore, make sure the unit has been installed so that the power cord can be easily unplugged from the AC outlet in case of an accident. To avoid fire hazard, the power cord should also be unplugged from the AC outlet when left unattended for a long period of time (for example, when on vacation).	
When using this product, confirm the safety information shown on the bottom of the unit.	
The graphical symbol ~ placed on the product means alternating current. The graphical symbol ~ placed on the product means direct current. The graphical symbol ~ placed on the product means Class II equipment.	
CAUTION This product is evaluated in moderate and tropical climate condition.	
[for a service technician] CAUTION Since the fuse may be in the neutral of the mains supply, disconnect the mains to de-energize the phase conductors.	
WARNING Store small parts out of the reach of children and infants. If accidentally swallowed, contact a doctor immediately.	
WARNING Do not touch any part of the reach of children and infants. If accidentally swallowed, contact a doctor immediately.	
POWER-CORD CAUTION Handle the power cord as the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or on the cord. Never make a knot in the cord or tie it with other cords. The power cords should be routed such that they are not likely to be stepped on. A damaged power cord can cause a fire or give you an electrical shock. Check the power cord once in a while. When you find it damaged, ask your nearest service center or your dealer for a replacement.	
○ switch Turn this unit on and off.	
• This unit should not be used by persons who have heart pacemakers installed, since adverse effects could occur. • Do not use this unit in hospitals or clinics, or near medical equipment. • Do not use inside airplanes or in the vicinity of automatic doors to avoid danger of causing malfunctions.	

Private households in the member states of the EU, in Switzerland, Norway, Iceland, Liechtenstein and UK may return their used electronic products free of charge to designated collection facilities or to a retailer (if you purchase a similar new one).

For countries not mentioned above, please contact your local authorities for the correct method of disposal.

By doing so you will ensure that your disposed product undergoes the necessary treatment, recovery and recycling and thus prevent potential negative effects on the environment and human health.

For Finland customers: Appareet mit illoksidat stikkontakti
For Sweden customers: Apparatet ska anslutas till jordat uttag
For Denmark customers: Apparatet skloppe skal tilsluttes en stikkontakt med jord, som giver forbindelse til sløjfeprops jord.

For U.S.A., U.S. Territories, and Canada
The Safety of Your Ears is in Your Hands
Get the most out of your equipment by playing it at a safe level - a level that lets the sound come through clearly without annoying ringing or distortion and, most importantly, without affecting your sensitive hearing. Sound can be deceiving. Over time, your "hearing comfort" level adjusts to higher volumes of sound, so what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adjusts.

ESTABLISH A SAFE LEVEL:
• Set your volume control at a low setting.
• Slowly increase the sound level until you can hear it comfortably and clearly, without distortion.
• Once you have established a comfortable sound level, set the dial and leave it there.

BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:
• Do not turn the volume up so high that you can't hear what's around you.
• Use caution or temporarily discontinue use in potentially hazardous situations.
• Do not use headphones while operating a motorized vehicle, the use of head phones may create a traffic hazard and is illegal in many areas.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

WARNING
Kleine Zetten offeren vlammen (z.B. eine brennende Kerze) auf dieses Gerät stellen. Türen, um Einfunktionen zu vermeiden.

USB Downstream-Bereich (USB)		Verwendetes Frequenzband..... 2,4 GHz/5,0	
Port.....	Stromversorgung..... 5 V11 A oder weniger	NFC-Bereich	
Port.....	Stromversorgung..... 5 V11 A oder weniger	Unterstützte Standards..... ISO/IEC 15693 (T)	
USB-Upstream-Bereich (USB)		• Die technischen Daten und das Design dieses Produkts können ohne vorherige Ankündigung geändert werden.	
LAN (PRO DI LINK).....		• Es kann garantiert werden, dass dieses Produkt mit allen WLAN-, Bluetooth-, NFC-fähigen Geräten verbunden werden kann.	
.....		• Da die meisten Geräte ein 2,4-GHz-Frequenzband verwenden, kann es durch elektromagnetische Störungen zu einer Verlangsamung der WLAN-Übertragung kommen. Für eine stabile Übertragung verwenden Sie bitte ein 5-GHz-Frequenzband.	
Display-Hauptbild			
Bildschirmgröße..... 10,1 Zoll			
WLAN			
Unterstützte Standards..... IEEE 802.11 a/b/g/n/ac			

